Download Realtek HD Audio Manager and the Realtek High Definition Audio Drivers. Then install both and configure using the HD Audio Manager. Don't forget to check the "Speaker Fill" box or you will only have stereo instead of surround.