
Subject: Re: Motherboards.....Again

Posted by [nikki6ixx](#) on Fri, 25 Jun 2010 06:53:48 GMT

[View Forum Message](#) <> [Reply to Message](#)

Awesome news!

Ok, increasing the multiplier by 10, which is 16 to 26 is a bad idea lol. Word to the wise, never do anything drastic like that as you can risk messing up your computer. Always take it slow.

To OC to 3.4GHz, all you'll need to do is set your multiplier to 17 in the BIOS. Also, disable Cool n' Quiet.

After that, save everything, exit the BIOS, and stress test your CPU with a program like Prime 95.

I wouldn't use AsRock's software to fiddle with that stuff anyways. AMD Overdrive, which you can download from AMD's site is a great tool that lets you monitor temperatures, and customize your system.
