

---

Subject: Re: USB Ports

Posted by [Tupolev TU-95 Bear](#) on Mon, 21 Jun 2010 19:17:07 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Zeratul wrote on Mon, 21 June 2010 19:47I think this may be a sign my USB ports are fucked

i was copying music files from my flash drive to my PSP soon a message popped up saying "Down - New Orleans is a Dying Whore" is no longer located in O:/blablablablablabla and then PSP was no longer connected through USB due to the message on the PSP "if the host does not detect the connected system etc etc." and that the flash drive reconnected through USB. shortly afterwards i thought it was just a corrupted file and played it in WMP... it played all the way through so now my last idea is all thats left. I'm going to Google search this issue now.

The Google search results: NOT A DAMN THING

It could be that the USB dock ports were overused? or it could be the USB lead that connects to the USB port is fucked.

Tried it on another PC to see if it works?

---